

Energizer CHFCV
NiMH Battery Charger Owner's Manual

CAUTION

Your AA, AAA, C, D, and 9V Battery Charger is designed to charge Energizer Nickel Metal Hydride (NiMH) rechargeable batteries.

Do not charge Alkaline, Carbon Zinc, Lithium or any other battery not specified for this charger. Risk of electric shock. Dry location use only. Read instructions before use.

SAVE THESE INSTRUCTIONS

WARNING

This manual contains important safety and operating instructions for your charger. Before using your charger, read all instructions and cautionary markings on the battery charger, the batteries to be charged, and the product that uses the batteries.

Charge only rechargeable Nickel Metal Hydride batteries. Charging any other type of rechargeable or non-rechargeable (disposable) batteries may cause them to leak, rupture or explode, resulting in injury or property damage.

Warnings:

OPERATING INSTRUCTIONS

1. To reduce the risk of injury, charge only rechargeable NiMH batteries with the charger. Other types of batteries might burst, causing personal injury or damage to your charger.
2. Do not charge batteries with different capacities at the same time.
3. For indoor use only. Do not expose charger to rain, snow or excessive moisture.
4. Never use an extension cord or any attachment not recommended by Energizer. May result in a risk of fire or electric shock.
5. Do not operate the charger if it has been subjected to shock or damage. Take it to a qualified serviceman for repair.
6. Do not disassemble the charger. Incorrect reassembly may result in a risk of electric shock or fire.
7. Always unplug the charger from outlet before attempting maintenance or cleaning.
8. Never alter the plug provided. Improper connection can result in a risk of electric shock.
9. Never use as a power source for any electrical equipment.

1. Insert the batteries in the charger as indicated in the charging slots.
2. For AA, AAA, C and D size batteries load 2 or 4 batteries. Load 1 or 2, 9-volt batteries.
3. Plug the charger into the proper AC outlet. When batteries are placed in the charger, one or two LED lights will glow in red indicating charging. (Refer to the table below for typical charge times) The LED will go off indicating charge completion

Approximate NiMH Battery Charge Time

AAA (500-550mAh)	3.5-4 hrs.
AAA (600-800mAh)	4.5-5 hrs.
AA (1100-1500mAh)	8-10.5 hrs.
AA (1600-1800mAh)	11-13 hrs.
AA (2100-2500mAh)	15-16.5 hrs.
C/D (2300-2600mAh)	16.5 hrs.
9V (110-150mAh)	10-13.5 hrs.

This Charger is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure they do not play with the charger.

NiMH BATTERY WARNING: Charge with only standard household Nickel Metal Hydride battery chargers. Do not open battery, dispose of in fire, put in backwards, mix with other battery types or short circuit - may ignite, explode, leak or get hot, causing injury.

Charger Features Include:

- * LED Charge Indicators
 - * Reverse Polarity Protection: Protects the charger and batteries against damage from incorrectly installed batteries.
 - * Designed to charge the following NiMH rechargeable battery sizes:
 - * AA (NH15) - 2 or 4 batteries at a time
 - * AAA (NH12) - 2 or 4 batteries at a time
 - * C (NH35) - 2 or 4 batteries at a time
 - * D (NH50) - 2 or 4 batteries at a time
 - * 9 volts (NH22) - 1 or 2 batteries at a time
- (Batteries must be charged in pairs according to specific battery sizes)



CONSUMER QUESTIONS OR STORE NEAREST YOU
CALL 1-800-383-7323 Visit us at www.energizer.com

Energizer and other marks are trademarks of Energizer
© 2005 Energizer
Sold by Energizer St Louis, MO 63141
Charger: Made in China.

UPN108576